



KANOMAX
The Ultimate Measurements

0.1 μ m Particle Counter Measurement Software for Windows

Model 3950

User Manual

Table of Contents

Table of Contents	1
§ 1 Overview	3
§ 2 Software Setup.....	4
§ 3 Main Unit Settings	7
§ 4 Using the Software	13
4.1 Starting the software (the Main Screen).....	13
4.2 Measurement procedures.....	14
§ 5 File	16
5.1 Open	16
5.2 Save	17
5.3 Exit.....	17
§ 6 Setting	18
6.1 Selecting the communication mode.....	18
6.2 Setting the IP address.....	19
6.3 RS-485 Setting	20
§ 7 Setting the Measurement Parameters and Start Measurement	
22	
7.1 Setting the measurement parameters	22
7.2 Start measurement.....	23
7.3 Stop measurement	24
§ 8 View	25
8.1 Setting the parameter in the particle graph.....	25
§ 9 Help	27
9.1 About	27
§ 10 Data Display Software: Measurement Screen	28
10.1 Data Display Software: Measurement Screen	28
§ 11 Communication Settings	31
11.1 Selecting the communication mode.....	31
11.2 Setting the IP address.....	32

11.3 Setting RS-485	33
§ 1 2 Measurement Settings	35
12.1 Measurement Mode Selection Screen	35
12.2 Measurement Mode.....	36
12.3 Starting Measurement	41
12.4 Stopping Measurement.....	41
§ 1 3 Troubleshooting	42
§ 1 4 Contact Information	44

§ 1 Overview

This manual describes how to operate the 0.1 µm Particle Counter Measurement Software. This software remotely controls the 0.1 µm Particle Counter. It monitors and displays the measured data. The data can be saved in CSV format.

1) Software Specifications

Item	Details
OS	Microsoft Windows 10
Language	English, Japanese
Communication Mode	TCP/IP (wired), Serial communication

2) Operating Environments

OS	Microsoft Windows 10
Interface	Ethernet, RS-485
RAM	4 GB or more
HDD Capacity	With free space of 500 MB or more
Compatible Model	Model 3950

§ 2 Software Setup

1) Prior to the software setup, exit other programs.



Open the folder English on the CD.



According to your Windows version, open 32bit or 64bit on the CD.



Double-click the setup file to display the dialog box as shown in Figure 2-1.



Figure 2-1 Initial Setup Dialog Box

- 2) Click the **Next** button to display the dialog box as shown in Figure 2-2. The default location to install is the C drive. To install into a different drive or a folder, click “Browse...” and choose the required location.




Figure 2-2 Select Installation Folder Dialog Box

- 3) Click the **Next** button to display the dialog box as shown in Figure 2-3.




Figure 2-3 Confirmation Installation Dialog Box

- 4) Click the **Next** button to display the dialog box as shown in Figure 2-4.




Figure 2-4 Installation progress Dialog Box

- 5) When the installation completed, the dialog box as shown in Figure 2-5 will appear.










Figure 2-5 Installation Complete Dialog Box

- 6) Click the **Close** button to complete the setup.

§ 3 Main Unit Settings

1) Settings the Main Unit Communication

<p>Step 1</p> <p>Turn on the Main unit to display the Main screen.</p> 	<p>Step 2</p> <p>On the Main screen, tap the Measurement Setting button to display the Measurement Setting screen below.</p> 				
<p>Step 3</p> <p>On the Measurement setting screen, tap the Remote button to display the Remote Control screen below.</p> 	<p>Step 4</p> <p>On the Remote Control screen, tap the Setting button to display the Remote Setting screen below.</p> 				
<p>Step 5</p> <p>Choose the communication method and set communication parameters.</p> <table border="1"> <thead> <tr> <th data-bbox="300 1480 826 1525">Ethernet</th><th data-bbox="831 1480 1358 1525">RS485</th></tr> </thead> <tbody> <tr> <td data-bbox="300 1532 826 1839">  </td><td data-bbox="831 1532 1358 1839">  </td></tr> </tbody> </table>		Ethernet	RS485		
Ethernet	RS485				
					
<p>Step 6</p>	<p>Step 7</p>				

<p>Tap the ✓ button to complete the setting. To return to the previous page, tap the Return button.</p> 	<p>The Remote measurement screen will appear, when connecting with the Connection button.</p> 
--	--

2) Connecting the Hardware

Ethernet direct connection between the main unit and the PC: Connect with a cross LAN cable as shown below.

Remote setting>Ethernet	Communication Parameters
	Port number : 502 IP address : 192.168.5.11 Subnet mask : 255.255.255.0 Default gateway : 0.0.0.0






Figure 3-1

If you connect the main unit and PC directly, you need to change the IP address of the PC.


- 1) Open the **Control Panel**.
- 2) Click the **Network and Internet**.




- 3) Click the **Network and Sharing Center**.




- 4) Click the **Change adapter settings**.




- 5) Right-click the **Ethernet** icon, and click the **Properties**.



- 6) Select the **Internet Protocol Version 4 (TCP / IPv4)** and click the **Properties**.



- 7) Select the **Use the following IP address**. Enter "192.168.5.1" in the **IP address**, "225.255.255.0" in the **Subnet mask**, and click the **OK**.



- 8) Close all the windows you opened.

Ethernet connection using LAN network: Using LAN cables to connect as shown in Figure 3-2, Figure 3-3.

Remote setting>Ethernet	Communication Parameters
Auto <input checked="" type="checkbox"/> :Checked	Obtain IP address, subnet mask, and gateway from the network automatically.
Auto <input type="checkbox"/> :No check	Enter the IP address, subnet mask, and gateway.




Figure 3-2 1-Device connection




Figure 3-3 2 or more Device connection

RS-485: If the PC does not have RS-485 communication port, use a 2-wire USB-RS485 converter.

Remote Setting > RS485	Communication parameters
Enter or select.	Enter the ID. Baud rate: 9600, 19200, or 38400 Parity: none, even, or odd Stop bit: 1 or 2




Figure 3-4 1-Device connection





Figure 3-5 2 or more Device connection

§ 4 Using the Software

4.1 Starting the software (the Main Screen)

Click the icon on the start-menu  to start the software. The main screen appears as shown in Figure 4-1.




Figure 4-1 Main Screen





Item	Details
Particle graph	Shows the value of the particle count
Data table	Shows the measurement data of particles
Status	(Contents in the table blow.)

Item	Details
Measurement status	Sampling, Waiting
Measurement parameter	Sampling time, Interval time, Repeat count
Communication mode	Ethernet, RS485



Open the Main screen. While holding down the **Ctrl** key, press the **D** key on the keyboard to display the Data Display Software: Measurement Screen (Chapter 10). For details, please refer to Chapter 10.


4.2 Measurement procedures

1) Configure the communication mode setting.

STEP1		STEP2	
Click the Select Communication Mode on the Set menu.		Select the Communication Mode.	
			
STEP3		STEP4	
Ethernet		RS485	
Set the IP address of the 0.1 μ m Particle Counter.		Set the communication parameters.	
			
		While the remote control of the 0.1 μ m Particle Counter. is on the stand-by, click the OK button to connect.	

2) Start a measurement.

STEP1	STEP2
<p>Click the Setting in the Measure menu.</p> 	<p>Set the parameters in the Measure Start Setting.</p> 

STEP3
<p>Click the Start Measurement on the Measure menu to start a measurement.</p> 

§ 5 File

Use this menu to open the existing data files, save the data files, and close the applications.






Figure 5-1 File Menu

5.1 Open

Open the data files (*.CSV) to display a particle graph and particle data. On the File Menu (Fig. 5-1), click  **Open** **Ctrl+O** to display the Opening Data File Dialog Box as shown in Figure 5-2.

(Using the  button on the toolbar or the **Ctrl** key + the **O** key on the keyboard are also allowed to access the dialog box in Fig. 5-2.)





Figure 5-2 Opening Data File Dialog Box


: Opens the data file.

: Cancels the command.

5.2 Save

Use this menu to save the measured data and the measurement parameters (*.CSV formats).

On the File Menu (Fig. 5-1), click  **Save** **Ctrl+S** to open the Save As Dialog Box as shown in Figure 5-3.

(Using the  button on the toolbar or the **Ctrl** key + the **S** key on the keyboard are also allowed to access the dialog box in Fig. 5-3.





Figure 5-3 Save As Dialog Box

 : Saves the data file.

 : Cancels the command.

5.3 Exit

On the File Menu (Fig. 5-1), click the **Exit** button to complete.

§ 6 Setting

Use this menu to set the communication mode and the communication parameters. Select the measurement mode before starting a measurement.





Figure 6-1 Setup Menu

6.1 Selecting the communication mode

On the Setup Menu (Fig. 6-1), click the **Select Communication Mode** to open the Select Communication Mode Dialog Box as shown in the Figure 6-2.

(Using the  button on the tool bar is also allowed to access the dialog box in Fig. 6-2.)





Figure 6-2 Select Communication Mode Dialog Box

Choose Ethernet or RS485.

 : Shows the parameter setting screen on the selected communication mode.

 : Cancels the command.

6.2 Setting the IP address

Using with the LAN cable, connect the PC and the 0.1μm Particle Counter.

Ethernet

On the Setup Menu (Fig. 6-1), click the **Ethernet Set** to display the Ethernet Setting Dialog Box as shown in Figure 6-3.





Figure 6-3 Ethernet Setting Dialog Box

1) Parameter settings

Enter the port number and the IP address set on the 0.1μm Particle Counter main unit.

2) Button functions

 : Saves the parameters and connects. When the connection completed, the **success** message will be displayed. When the connection is failure, a **failure** message will be displayed. If a connection error occurs, check the connection status.

 : Cancels the command.

6.3 RS-485 Setting

On the Setup Menu (Fig. 6-1), click the **RS485 Set** to open the RS 485 Setting Dialog Box as shown in Figure 6-4.


The image shows a software dialog box titled "RS485 Setting" with a close button (X) in the top right corner. Inside the dialog, there are seven configuration options, each with a label and a control element: "Port" with a dropdown menu showing "COM1"; "ID" with a dropdown menu showing "1"; "Baud Rate" with a dropdown menu showing "19200"; "Data Bit" with a text input field showing "8"; "Parity" with a dropdown menu showing "Even"; and "Stop Bit" with a dropdown menu showing "1". At the bottom of the dialog are two buttons: "Connect" and "Cancel".

Figure 6-4 RS485 Setting Dialog Box

Note: When setting the port, be sure to confirm the communication port connected to the main device and the PC.

1) Parameter settings

Enter the communication parameters set on the 0.1 μm Particle Counter main unit.

Item	Details	Remarks
Port	COM1, COM2 ... COM255	Selectable
ID	1, 2, 3 ... 247	Input possible
Baud rate	9600, 19200, 38400	Selectable
Parity	None, Even, Odd	Selectable
Data bit	8	Fixed
Stop bit	1 or 2	Selectable

2) Button functions

Connect

: Saves the parameters and opens the port. When the port is connected properly, the success message will appear. When a port error occurs, a failure message will appear. If a connection error occurs, check the connection status.

Cancel

: Cancels the command.

§ 7 Setting the Measurement Parameters and Start Measurement

Use this menu to set the measurement parameters, start a measurement, and stop a measurement.




Figure 7-1 Measure Menu

7.1 Setting the measurement parameters

Click the **Setting** on the Measurement Menu to display the Measure Parameter Set Dialog Box as shown in Figure 7-2.




Figure 7-2 Measure Parameter Set Dialog Box

1) Parameter Settings


Item	Details	Remarks
Sample time	6 to 5999 seconds	Possible to Input
Interval time	6 to 5999 seconds	Possible to Input
Sample cycle	1 to 9999 pcs.	Possible to Input
Size distribution	0.1 μm , 0.3 μm	Selectable

2) Button functions

 : Saves the measurement parameters.

 : Cancels the command.

7.2 Start measurement

On the Measure Menu (Fig. 7-1), click the **Start Measurement** .
(Using the  button is also the same function with the above.)

Measurement window





Figure 7-3 Measurement Window

7.3 Stop measurement

On the Measure Menu (Fig. 7-1), click the **Stop Measurement** to display the Confirm Message Dialog Box as shown in Figure 7-4.

(Using the  button on the tool bar is allowed to access the dialog box in Fig. 7-4.)





Figure 7-4 Confirm Message Dialog Box

 : Stops the measurement.

 : Cancels the command.

§ 8 View

Use this menu to set the particle graph.





Figure 8-1 View Menu

8.1 Setting the parameter in the particle graph

Click the **Particle Graph Parameter Edit** on the View Menu (Fig. 8-1) to display the Particle Graph Parameter Edit Dialog Box as shown in Figure 8-2.

(Using the  button on the toolbar is also allowed to access the dialog box in Fig. 8-2.)





Figure 8-2 Particle Graph Parameter Edit Dialog Box


1) Parameters

Item	Details	Remarks
Range of X-axis	1, 2, 3, 4, 5, 10, 20, 30, 40, 50, 60 minutes	Selectable
	3, 6, 12, 18, 24 hours	
	0, 20, 30 days	
Size distribution	0.1 μm , 0.3 μm	Selectable
Graph type	Linear graph, Logarithmic graph	Selectable
Range of Y-axis	10,20,50,100, ... 1.00E+9	Selectable

2) Button functions



: Saves the graph parameters.



: Cancels the command.

§9 Help

Use this menu to display the software title and version information.




Figure 9-1 Help Menu

9.1 About

Click the **About** on the Help Menu (Fig. 9-1) to display the About (version information) as shown in Figure 9-2.



Figure 9-2 About (Version information)

§ 1 0 Data Display Software: Measurement Screen

10.1 Data Display Software: Measurement Screen

Display the Main Screen (Fig. 4-1 in Chapter 4). While holding down the **Ctrl** key, press the **D** key on the keyboard. Perform a measurement on the same screen with the Main screen of the 0.1μm Particle Counter. main unit. The Data Software: Measurement Screen as shown in Figure 10-1 will appear.






Figure 10-1 Data Display Software: Measurement Screen (1-Device Connection)

1) Parameters

Item	Details
Measurement Value	Particle measurement data
Location No.	Setting location (No.)
Repeat Count	Count up to the number of times of a set repeat count
Remaining Time	Remaining time to the next step
Measurement Mode	Display a set measurement mode
Text Box	(Optional) Input texts up to 500 characters.
Data Saving Check Box	Indicate whether or not the measured data saving is required.
IP/ID Connection Information	For Ethernet connection, IP information is displayed. For RS485 connection, ID information is displayed.

2) Button functions

- Measure start** : Starts measurements in all connected devices.
- Measure stop** : Stops measurements in all connected devices.
- Measure setting** : Displays the Mode Selection Screen (Chapter 12).
- Communication setting** : Displays the Select Communication Mode Dialog Box (Chapter 11).
- Cumulative Σ** : Switches readings that represent each device between Cumulative Σ and Differential Δ .
-  : Starts/Stops measurements in each device.
-  : Displays the Mode Selection Screen (Chapter 12) of the device that the screen with this icon shows.

The layout of the Measurement Screen depends on how many devices (up to four devices) are connected. Checking the check box on the screens of **11.2 Setting the IP address** or **11.3 Setting RS-485** (Chapter 11. Communication Settings) allows you to designate the number of device to be connected.




Figure 10-2 Data Display Software: Measurement Screen (2-Device Connection)




Figure 10-3 Data Display Software: Measurement Screen (3-Device Connection)




Figure 10-4 Data Display Software: Measurement Screen (4-Device Connection)

Display the Data Display Software: Measurement Screen. While holding down the **Ctrl** key, press the **D** key on the keyboard to display the Main Screen (Fig. 4-1 in Chapter 4). For the operation of the Main Screen, please refer to Chapter 4.

§ 1 1 Communication Settings

In this chapter, set communication modes, communication parameters and the number of device to be connected.

Select the measurement mode before starting a measurement.


 Communication setting

Figure 11-1 Communication Setting Button

11.1 Selecting the communication mode

Click the Communication Setting Button on the Measurement Screen to display the Select Communication Mode Dialog Box as shown in Figure 11-2.





Figure 11-2 Select Communication Mode Dialog Box

Choose Ethernet or RS485.

 : Shows the parameter setting screen on the selected communication mode.


 : Cancels the command.

11.2 Setting the IP address

Using with the LAN cable, connect the PC and the 0.1μm Particle Counter.

Ethernet

On the Setup Menu (Fig. 11-2), click the **Ethernet Set** to display the Ethernet Setting Dialog Box as shown in Figure 11-3.



Multiple Ethernet settings

Port: 502

☒ IP Address: 192 . 168 . 5 . 11

☒ IP Address: 192 . 168 . 5 . 12

☒ IP Address: 192 . 168 . 5 . 13

☒ IP Address: 192 . 168 . 5 . 14

Connect Cancel

Figure 11-3 Ethernet Setting Dialog Box


1) Setting Parameter

Checking the check box of the IP Address allows you to enter IP address.

Check the check box to meet the number of device to be connected.

Enter the port number and the IP address set on the 0.1μm Particle Counter main unit.

2) Button functions

 : Saves the parameters and connects. When the connection completed, the **success** message will be displayed. When the connection is failure, a **failure** message will be displayed. If a connection error occurs, check the connection status.

 : Cancels the command.

11.3 Setting RS-485

On the Setup Menu (Fig. 11-2), click the **RS485 Set** to open the RS 485 Setting Dialog Box as shown in Figure 11-4.

Multiple RS485 settings

Port: COM1

☒ ID: 1

☒ ID: 2

☒ ID: 3

☒ ID: 4

Baud Rate: 19200

Data Bit: 8

Parity: None

Stop Bit: 1

Connect Cancel

Figure 11-4 RS485 Setting Dialog Box

Note: When setting the port, be sure to confirm the communication port connected to the main device and the PC.

1) Parameter settings

Checking the check box of the ID allows you to enter ID.

Check the check box to meet the number of device to be connected.

Enter the communication parameters set on the 0.1 μ m Particle Counter main unit.

Item	Details	Remarks
Port	COM1, COM2 ... COM255	Selectable
ID	1, 2, 3 ... 247	Input possible
Baud rate	9600, 19200, 38400	Selectable
Parity	None, Even, Odd	Selectable
Data bit	8	Fixed
Stop bit	1 or 2	Selectable

2) Button functions

Connect

: Saves the parameters and opens the port. When the port is connected properly, the success message will appear. When a port error occurs, a failure message will appear. If a connection error occurs, check the connection status.

Cancel

: Cancels the command.

§ 1 2 Measurement Settings

Configure each parameter in the measurement mode.



Figure 12-1 Measurement Setting Button

Measure setting

Figure 12-2 Batch Processing Measure Setting Button

12.1 Measurement Mode Selection Screen

Click the Individual Processing Measurement Setting Button (Fig. 12-1) or the Batch Processing Measure Setting Button (Fig. 12-2) on the Measurement Screen to display the Mode Selection Screen as shown in Figure 12-3.

When clicking the Individual Processing Measurement Setting Button, IP/ID information will be displayed as a window-name as shown in Figure 12-4.





Figure 12-3 Mode Selection Screen

Mode selection (IP:192.168.5.11)

Figure 12-4 Display of Window-Name

When Clicking Individual Processing Measurement Setting Button

1) Button functions



: Use this button to display the screen to set up the Repeat mode.



: Use this button to display the screen to set up the Single mode.



: Use this button to display the screen to set up the Continuous mode.



: Use this button to display the screen to the Calculation mode.



: Use this button to close the current screen.

12.2 Measurement Mode

When the Mode Selecting Screen (Fig. 12-3) is displayed by clicking the Individual Processing Measurement Setting Button (Fig. 12-1), IP or ID information will be displayed as a window-name.

In this case, only measurement modes in the screen that applies can be set.

When the Mode Selecting Screen is displayed by clicking the Batch Processing Measure Setting Button (Fig. 12-2), measurement modes in all the screens can be set.

1) Repeat Mode

Click the **Repeat** button on the Mode Selection Screen (Fig. 11-3) to display the Repeat Mode as shown in Figure 12-5.

Mode setting

Repeat Mode

Location (1-99) 1

Sampling Time (6s-99m59s) 0 min 6 sec

Repeat Count (2-9999) 2

Interval Time (6s-99m59s) 0 min 6 sec

Figure 12-5 Repeat Mode

1-1) Parameter Settings

Item	Details	Remarks
Location	1 to 99	Possible to input
Sampling Time	6 s to 99 m 59 s	Possible to input
Repeat Count	2 to 9999	Possible to input
Interval Time	6 s to 99 m 59 s	Possible to input

1-2) Button functions



: Use this button to cancel the setting and close the current window.



: Use this button to save the setting and display the Data Display Software: Measurement Screen. (Fig. 10-1)

2) Single Mode

Click the **Single** button on the Mode Selection Screen (Fig. 12-3) to display the Single Mode screen as shown in Figure 12-6.




Figure 12-6 Single Mode

2-1) Parameter Settings

Item	Details	Remarks
Location	1 to 99	Possible to input
Sampling Time	6 s to 99 m 9 s	Possible to input

2-2) Button functions



: Use this button to cancel the setting and close the current screen.



: Use this button to save the setting and display the Data Display Software: Measurement Screen. (Fig. 10-1)

3) Continuous Mode

Click the **Continuous** button on the Mode Selection Screen (Fig. 12-3) to display the Continuous Mode shown in Figure 12-7.




Figure 12-7 Continuous Mode

3-1) Parameter Settings

Item	Details	Remarks
Location	1 to 99	Possible to input

3-2) Button functions




: Use this button to cancel the setting and close the current screen.



: Use this button to save the setting and display the Data Display Software: Measurement Screen. (Fig. 10-1)

4) Calculation Mode

Click the **Calculation** button on the Mode Selection Screen (Fig. 12-3) to display the Calculation Mode as shown in Figure 12-8.



The screenshot shows a window titled "Mode setting" with a close button (X) in the top right corner. The main area has a dark blue background with the title "Calculation Mode" in light blue. On the left side, there are two blue buttons: one with a white left-pointing arrow and another with a white checkmark. The settings are as follows:

- Location (1-99): A text input field containing the number "1".
- Sampling Time (6s-99m59s): Two numeric input fields, the first containing "0" and the second containing "6", with "min" and "sec" labels between them.
- Repeat Count (2-9999): A text input field containing the number "2".
- Interval Time (6s-99m59s): Two numeric input fields, the first containing "0" and the second containing "6", with "min" and "sec" labels between them.

Figure 12-8 Calculation Mode

4-1) Parameter Settings

Item	Details	Remarks
Location	1 to 99	Possible to input
Sampling Time	6 s to 99 m 59 s	Possible to input
Repeat Count	2 to 9999	Possible to input
Interval Time	6 s to 99 m 59 s	Possible to input

4-2) Button functions





: Use this button to cancel the setting and close the current screen.





: Use this button to save the setting and display the Data Display Software: Measurement Screen. (Fig. 10-1)

12.3 Starting Measurement

Click  or  to start measurement.

12.4 Stopping Measurement

Click  or  to stop measurement.

If you have checked the Data Saving Check Box in advance and there are valid results, when the measurement is completed, or stopped by tapping the button, the File Saving Dialog Box will appear. The results can be stored. (*.CSV format)






Figure 11-8 File Saving Dialog Box



: Tap this button to save data.




: Tap this button to cancel the current command.

§ 1 3 Troubleshooting


When using the RS485-USB conversion cable (hereinafter, the “conversion cable”), if communication errors occur repeatedly, the change of the device settings for the conversion cable can result in avoiding communication errors.

(Example) If FTDI Chip’s conversion cable is used,

- Open the Device manager.



- Expand **Port (COM and LPT)**, and right-click the **USB Serial Port (COMx)**. Choose **Properties** on the menu and click **Properties**.
- Click **Advanced** on the Port Settings.



- When the Advanced Setting screen appears, change **Latency Timer** in the BM Options from 16msec to 1msec, then click **OK**.
Close the properties screen to complete the settings.

Advanced Settings for COM3

COM Port Number: COM3

OK

Cancel

Defaults

USB Transfer Sizes

Select lower settings to correct performance problems at low baud rates.

Select higher settings for faster performance.

Receive (Bytes): 4096

Transmit (Bytes): 4096

BM Options

Select lower settings to correct response problems.

Latency Timer (msec): 16

Timeouts

Minimum Read Timeout (msec): 0

Minimum Write Timeout (msec): 0

Miscellaneous Options

Serial Enumerator ☒

Serial Printer ☐

Cancel If Power Off ☐

Event On Surprise Removal ☐

Set RTS On Close ☐

Disable Modem Ctrl At Startup ☐

Enable Selective Suspend ☐

Selective Suspend Idle Timeout (secs): 5

§ 1 4 Contact Information



□ U.S.A.

KANOMAX USA, INC.

PO Box 372, 219 Route 206, Andover, NJ 07821 U.S.A.

TEL: (800)-247-8887 / (973)-786-6386

FAX: (973)-786-7586

URL: <http://www.kanomax-usa.com/>

E-Mail: info@kanomax-usa.com

□ JAPAN

KANOMAX JAPAN INC.

2-1 Shimizu, Suita City, Osaka 565-0805, Japan

TEL: 81-6-6877-0183

FAX: 81-6-6879-5570

URL: <http://www.kanomax.co.jp>

E-Mail: sales@kanomax.co.jp

□ CHINA

Shenyang Kano Scientific Instrument Co., Ltd.

TEL: 86-24-23846440

FAX: 86-24-23898417

URL: <http://www.kanomax.com.cn/>

E-mail: sales@kanomax.com.cn

01001/1908

