

携帯型アネモマスター計測ソフトウェア for Windows MODEL 6000-40



○概要

通信機能があるアネモマスター・クリモマスターでご利用いただける計測ソフトウェアです。測定値をリアルタイムでグラフ表示も可能です。測定データ、時系列グラフ、最大・最少・平均値の表示や測定パラメータの設定などがソフトウェア上で行うことができます。測定データはCSV形式、またはテキスト形式で保存されますので、Excelなどの表計算ソフトウェアにも簡単に取り込みができます。また、風速計本体に記憶されているデータをパソコンへ転送することもできます。

○動作環境

OS	Windows Vista/7
CPU	Pentium 50MHz 以上
メモリ	8MB 以上の空き容量
HDD	10MB 以上の空き容量
対象器種	6501 シリーズ、6113、6114、6115、6162

○画面構成

The screenshot shows the software interface with the following components labeled:

- メニューバー** (Menu Bar): Located at the top, containing options like 'ファイル(F)', '設定(S)', '測定(M)', '転送(T)', '表示(V)', 'オプション(O)', 'ウインドウ(W)', and 'ヘルプ(H)'.
- ツールバー** (Toolbar): Located below the menu bar, containing icons for file operations and measurement.
- ファイル名** (File Name): Located below the toolbar, showing the current file name 'NewFile.KMA'.
- データテーブル** (Data Table): Located on the right side, displaying a table of measurement data with columns for No., V(m/s), T(C), and H(%RH).
- ステータスバー** (Status Bar): Located at the bottom, showing the device ID '6531' and other status information.
- 時系列グラフ** (Time Series Graph): Located in the center, displaying a graph of wind speed (V), temperature (T), and humidity (H) over time.
- 測定パラメータ** (Measurement Parameters): Located at the bottom right, displaying settings for RS232c, wind speed sensor, C-MODE, S-TIME(S), and No. TRIAL.

※ソフトウェアを使用するには別売りの通信ケーブルが必要な場合があります。詳しくはお問い合わせください。