

携帯型アネモマスター計測ソフトウェア for Windows MODEL 6000-40



○概要

通信機能があるアネモマスター・クリモマスターでご利用いただける計測ソフトウェアです。測定値をリアルタイムでグラフ表示も可能です。測定データ、時系列グラフ、最大・最少・平均値の表示や測定パラメータの設定などがソフトウェア上で行うことができます。測定データはCSV形式、またはテキスト形式で保存されますので、Excelなどの表計算ソフトウェアにも簡単に取り込みができます。また、風速計本体に記憶されているデータをパソコンへ転送することもできます。

○動作環境

OS	Windows XP SP3 以降、Windows Vista SP2 以降、Windows 7 SP1 以降、Windows 10 の日本語版あるいは英語版
CPU	Pentium 50MHz 以上
メモリ	8MB 以上の空き容量
HDD	10MB 以上の空き容量
対象器種	6501 シリーズ、6113、6114、6115、6162

○画面構成

The screenshot shows the software interface with the following components labeled:

- メニューバー** (Menu Bar): Located at the top, containing options like File (F), Settings (S), Measurement (M), Transfer (T), Display (V), Options (O), Window (W), and Help (H).
- ツールバー** (Toolbar): Located below the menu bar, containing icons for file operations and measurement functions.
- ファイル名** (File Name): Located below the toolbar, showing the current file name 'NewFile.KMA'.
- データテーブル** (Data Table): Located on the right side, displaying a table of measurement data with columns for No., V(m/s), T(C), and H(%RH).
- ステータスバー** (Status Bar): Located at the bottom, showing the file number '6531' and options like '新規ファイル' (New File), 'データ有り' (Data Present), and 'データ変更有り' (Data Change Present).
- 時系列グラフ** (Time Series Graph): Located in the center, showing a graph of wind speed (V), temperature (T), and humidity (H) over time. The x-axis is labeled 'Sample No.' and the y-axis shows values for V, T, and H.
- 測定パラメータ** (Measurement Parameters): Located at the bottom right, showing settings for RS232c (COM1, 19200bps), Wind Speed (6531 (VTH)), C-MODE (Average (Original T.)), S-TIME(S) (2), and No. TRIAL (100).

※ソフトウェアを使用するには別売りの通信ケーブルが必要な場合があります。詳しくはお問い合わせください。