

AccuFIT9000 ハードタイプキャリングケース (MODEL 3000-77)

取扱説明書

本製品は AccuFIT9000 専用のキャリングケースです。(対応機種: 3000-00、3000-0A、3000-0C) 本製品には AccuFIT9000 本体の他、AccuFIT9000 の付属品が収納できます。

■使用方法



AccuFIT9000 ハードタイプキャリングケース

AC アダプター、 電源ケーブル、 USB ケーブル等を収納

電源ボタンを手前側にして収納

USB メモリー、 ネックストラップ、 ゼロチェック HEPA フィルター、 ツインチューブ等を収納

アルコールボトルを収納

プローブ取付治具を収納

- ・AccuFIT9000を収納する際、装置本体に保存キャップを取り付け、上図の方向に収納してください。
- ・アルコールカートリッジはアルコールボトルに取り付けて収納してください。
- ・アルコールボトルをキャリングケースに収納する際は、IPA 等液体を廃棄してから収納してください。
- ・収納した後は、キャリングケースを確実に閉め、キャリングケースのラッチを確実に閉じてください。

保存キャップ

■使用上の注意

- ・キャリングケースの取っ手側の面を下側に傾けないでください。装置本体の検出部に IPA が入り、故障 の原因となる恐れがあります。
- ・内装スポンジはキャリングケースから取り外さないでください。
- ・移動時など、大きなショックを与えないよう注意してください。
- ・直射日光が当たる車の中などに放置しないでください。
- ・汚れを落とす場合は、水分を含んだ布をよく絞ったもので拭き取ってください。

■仕様

材 質: ケース:強化 PP、内装材:ポリウレタンフォーム

重 量:約4.5kg

外形寸法: W 503 × D 409 × H 254 mm

使用温度:-20~50℃ 保護等級:IP65

お問い合わせ先



日本カノマックス株式会社

〒565-0805 大阪府吹田市清水 2番 1号

カスタマーサポート TEL 0120-009-750 E-mail: environment@kanomax.co.jp

□ 東京営業所 〒105-0013 東京都港区浜松町2丁目6番2号

TEL: (03) 5733-6023 FAX: (03) 5733-6024

□ 大阪営業所 〒565-0805 大阪府吹田市清水 2番1号

TEL: (06) 6877-0447 FAX: (06) 6877-8263

□ 名古屋営業所 〒460-0002 愛知県名古屋市中区丸の内 3-7-26 丸の内 ACA ビル 603 号室

TEL: (052) 953-5660 FAX: (052) 953-5661



AccuFIT9000 Hard Type Carrying Case (MODEL 3000-77) User's Manual

This hard carrying case is designed exclusively for AccuFIT9000. (Compatible models: 3000-00, 3000-0A, and 3000-0C)

This carrying case can hold the AccuFIT9000 main unit and their accessories.

■ How to use



AccuFIT9000 Hard Type Carrying Case

AC adapter,
Power cord,
USB cable, etc.

Store the main unit with the power button facing you.

USB memory, N95 Neck strap Zero-check HEPA filter, Twin tube

Alcohol storage container

Probe attachment tool

- •When storing the AccuFIT9000, attach the storage cap to the main unit, and place and store it in the correct orientation as the photo above shows.
- •Prior to storing alcohol cartridges in the carrying case, install the cartridge in the alcohol storage container.
- •Prior to storing the alcohol storage container in the carrying case, dispose of IPA and any other liquid .
- ·After storing, appropriately close the carrying case, and close its latch completaly.



Storage cap

■ Precautions for use

- •Do not tilt the handle side of the carrying case downward. Doing so may cause IPA to enter the the detector inside the main unit, resulting in malfunction.
- •Do not remove the inner polyurethane foam from the carrying case.
- $\boldsymbol{\cdot} \mathsf{Do}$ not give a shock to the case during carrying or transportation.
- •Do not leave the case in a car or any other place where it will be exposed to direct sunlight.
- •To remove a stain, wipe it off with a moist cloth wrung out well.

■ Specification

Material: Reinfoeced PP (Case), Polyurethane foam (Interior material)

Weight: Approximately 4.5 kg

External dimensions: W 503 \times D 409 \times H 254 mm

Operating temperature: -20 to 50°C

Protection class: IP65

For inquiries, please contact



KANOMAX JAPAN INC.

2-1 Shimizu Suita City, Osaka 565-0805, Japan **TEL:** +81-6-6877-0183 **FAX:** +81-6-6877-5570

URL: https://www.kanomax.co.jp/ **E-mail:** sales@kanomax.co.jp